

Manufacturer's Instructions and User Information

Name and Address of the manufacturer: Impacto Protective Products Inc.
PO Box 524, Belleville, ON K8N 5B2 Canada

Style Identification: ARMORSTEP

Description: **IMPACTO® PUNCTURE RESISTANT ARMORSTEP™ INSOLES.**
POLYURETHANE UNDERSOLE WITH STAINLESS STEEL PLATE.
ORTHOTIC SUPPORT SYSTEM CONSISTS OF HEEL CUP,
LONGITUDINAL ARCH SUPPORT AND METATARSAL SUPPORT. FABRIC
COVER WICKS AWAY MOISTURE. HYPOALLERGENIC. 100% PVC-FREE.



These garments bear CE marking to demonstrate compliance with EU 2016/425 Personal Protective Equipment Annex II Health & Safety Requirements.

EU Declaration of Conformity: <https://www.impacto.ca/products/datasheet-ce-conformity-statements/>

Fitting Instructions:

Using the correct size is important. To determine the proper size, refer to the sizing chart on the other side. Remove existing insoles from shoes. Insert the insoles into shoes and check for correct fit. If necessary trim the front of the insoles. Do not trim the heel area. ADAPTATION PERIOD Depending on the individual some break-in time may be required. If so, please wear your new insoles for up to two hours the first day, four hours the second day, and six hours the third day. This break-in time allows your foot and body to adjust to the ARMORSTEP insoles and correct body alignment.

Part#	USA Men	USA women	UK	Europe
ARMORSTEPA	5 - 6	7 - 8	4.5 - 5.5	37 - 38
ARMORSTEPB	7 - 8	9 - 10	6.5 - 7.5	39 - 41
ARMORSTEPC	9 - 10	11 - 12	8.5 - 9.5	43 - 44
ARMORSTEPD	11 - 12	13 - 15	10.5 - 11.5	45 - 46
ARMORSTEPE	13 - 15		12.5 - 13	47 - 49
ARMORSTEPA	5 - 6	7 - 8	4.5 - 5.5	37 - 38

WEIGHT: 0.40 LB. SOLD PER PAIR. CASE: 20.

Washing Instructions:

Hand wash with lukewarm water and soft detergent. Hang to Dry.

Limitations of Use:

The ARMORSTEP insoles are designed to resist punctures caused by accidentally stepping on objects, such as nails, under normal working conditions. Not designed to resist punctures from pneumatic or power actuated tools. Any attempt to do so may result in serious injury to the user. Not designed to resist punctures resulting from intentional acts.

After Care:

Follow the manufacturer's recommendations for washing and cleaning. To ensure optimum protection, regular comparisons are recommended against a new product. This product is warranted against defects in materials and workmanship for one year from the time of purchase. There are no other warranties expressed or implied. The company will not accept liability for product, whose use and care advice has been ignored.

EU DECLARATION OF CONFORMITY

We,

Impacto Protective Products Inc.
PO Box 524
Belleville, ON K8N 5B2
Canada

Declare that the PPE described here after,

ARMORSTEP

These garments bear CE marking to demonstrate compliance with EU
2016/425 Personal Protective Equipment Annex II Health & Safety Requirements.

this declaration of conformity is self-certified and issued under the sole responsibility of the
manufacturer;

The technical Construction File is maintained at the following addresses:

1. Impacto Protective Products Inc.
PO Box 524
Belleville, ON K8N 5B2 Canada
Tel 0613 9660 062
Fax 0613 9660 067
UK free phone 0800 0280 243
Email impacto@impacto.ca
Contact Mr. Eric Lehtinen

Authorized Signatory



Date Sep 9, 24

Name:

Eric Lehtinen

Position:

President
Impacto Protective Products Inc.