

Manufacturer's Instructions and User Information

Name and Address of the manufacturer: Impacto Protective Products Inc.
PO Box 524, Belleville, ON K8N 5B2 Canada

Style Identification: TS199

Description: **IMPACTO® Anti-fatigue Thermo glove.** Open finger tips ensure tactile feedback. Protects the hand and fingers from strain and fatigue when doing repetitive tasks. Lining wicks away moisture. Keeps hands warm to provide therapeutic support and compression. Hook/loop wrist closure.



These garments bear CE marking to demonstrate compliance with EU 2016/425 Personal Protective Equipment Annex II Health & Safety Requirements. Declaration of Conformity: <https://www.impacto.ca/products/datasheet-ce-conformity-statements/>

Fitting Instructions:

This garment can be used prior, during and after activities to help PREVENT repetitive strain injuries. Wear lining directly against the skin.

Insert fingers through openings and faster hook and loop closure at wrist. Fit should be firm but not tight. Sizes are as detailed below designed to ensure close fitting to maximise comfort and performance.

Glove Size	Fits hand Size	Hand Circumference	Length
XSmall	6 (XS)	6"-7" / 15-28 cm / 152-177 mm	160 – 70 mm
Small	7 (S)	7"-8" / 18-20 cm / 178 – 202 mm	171 – 181 mm
Medium	8 (M)	8"-9" / 20-23 cm / 203 – 228 mm	182 – 191 mm
Large	9 (L)	9"-10" / 23-25 cm / 229 – 2538 mm	192 – 203 mm
X-Large	10 (XL)	10"-11" / 25-28 cm / 254 – 278 mm	204 – 214 mm
XX-Large	11 (XXL)	11"+ / 28+ cm / 279 mm	215 mm

Weight (LB): 0.30. Sold per Pair. Case: 24.

Washing Instructions:

Machine washable with lukewarm water and mild detergent. Do not use bleach or strong detergent. Hang or lay flat, air dry. Do not dry in automatic dryer. Wash daily if worn during heavy activity.

Limitations of Use:

Glove components used are not harmful for the user and have been selected for best wearing comfort. List of substances contained in the glove which are known to cause allergies: none. A list of raw substances is available upon request.

After Care:

Follow the manufacturer's recommendations for washing and cleaning. To ensure optimum protection, regular comparisons are recommended against a new product. This product is warranted against defects in materials and workmanship for one year from the time of purchase. There are no other warranties expressed or implied. The company will not accept liability for product, whose use and care advice has been ignored.

EU DECLARATION OF CONFORMITY

We,

Impacto Protective Products Inc.
PO Box 524
Belleville, ON K8N 5B2
Canada

Declare that the PPE described here after,
TS199, TS204, TS205, TS208, TS209, TS212, TS213, TS214, TS215, TS216, TS217,
TS226, HS226, TS228, TS230, TS242, TS243, TS299

These garments bear CE marking to demonstrate compliance with EU
2016/425 Personal Protective Equipment Annex II Health & Safety Requirements.

this declaration of conformity is self-certified and issued under the sole responsibility of
the manufacturer;

The technical Construction File is maintained at the following addresses:

1. Impacto Protective Products Inc.
PO Box 524
Belleville, ON K8N 5B2 Canada
Tel 0613 9660 062
Fax 0613 9660 067
UK free phone 0800 0280 243
Email impacto@impacto.ca
Contact Mr. Eric Lehtinen

Authorized Signatory



Date Sep 9, 24

Name:

Eric Lehtinen

Position:

President
Impacto Protective Products Inc.